

Inside the box you will find:

A: 4 x M8 hexagonal bolts + washers + nuts

B: 1 x M10 hexagonal bolt + 2 washers+ nut

C: 1 x Specific BMW E36/E46 seat bracket

D: 1 x Sparco sliders



BOTTOM MOUNT BMW E36/E46 MOUNTING INSTRUCTIONS

1

Face the part D with the seat, the position it's very important, the widest part must go attached to the seat as shown in pictures. Bolts for this are not included, this must come with the seat and in case not, normally you have to use 4 M8 Allen bolts. Before facing the second adjustable rail you must adjust the lever regarding the distance between both adjustable rails than set the lever and tighten the bolts.

2

Screw the part C to the part D already mounted in your seat using the part A.

3

Screw the stock seat belt anchor on the bracket with the part B. Normally you have to use the rear seats seat belt anchor.

4

Finally place all the set on the car and screw the Nisuba seat bracket to your car, make sure that all bolts are tighten and check if the part D works correctly.

