

SL TYPE SEAT BRACKETS MOUNTING INSTRUCTIONS

Inside the box you will find:

- A: 1 x Sparco sliders
- B: 4 x M8 allen bolt + washer + nut
- C: 4 x M8 hexagonal bolt + washers + nut
- D: 1 x M10 hexagonal bolt + washer + nut
- E: 1 x Specific floor bracket
- F: 2 x Seat brackets



TYPE SL

- 1 Join the Sparco sliders (A) to the specific floor bracket (E) using part B.
- 2 Join the seat brackets (F) to the Sparco sliders (A) using (C).
- 3 Bolt the stock seat belt anchor to the seat belt anchor mounting point in the specific floor bracket (E) using part D.
- 4 Bolt the joined parts to the car. Bolt the seat between the two seat brackets (D) and finally tighten all the nuts (Bolts not included).